

LED Projector Digital Alarm Clock



User Manual

tzumi




PRODUCT FEATURES

Illuminate any dark room with the LED Projector Alarm Clock by tzumi. This compact clock lights up with a bright, colorful LED and lights up your ceiling with a projection of the time or a relaxing moon and star shapes to help you fall asleep. Makes the perfect gift for children or adults, or for adding some subtle color to your bedroom.

PACKAGE CONTENTS:

- 1 LED Projector Digital Alarm Clock
- User Manual
- 3 AAA Batteries Required (Not Included)

PRODUCT OVERVIEW & FUNCTIONS



- Front & Top Projector LCD Time Displays
- Colorful LED Nightlight
- Comforting Moon & Stars Ceiling Projector
- Displays the Time, Alarm and Date (Month/Day)

HOW TO USE YOUR CLOCK

NOTE:
 - As soon as you turn the power ON, the projection function will begin with the LED lights.
 - If your battery life is low, the light will be faint. Change the batteries to restore to the brighter light setting. The date, time, and alarm settings will all be restored once the batteries have been changed.

STEP 1: INSTALL THE BATTERIES.

- Insert the 3 AAA batteries into the compartments as shown and replace the covers by snapping them back into place. You will hear a "click" when each is secured in its place and the clock will display a default time setting.
- a) Press the ADJ button once to display the alarm time.
- b) Press the ADJ button twice to display the date (month and day).
- c) Press the ADJ button a third time to display the current seconds.
- d) Press the ADJ button a fourth time to display the current time again.

STEP 2: SET THE ALARM.

- Press the SET button once to display the alarm time.
- Press the SET button again and use the ADJ button to change the hours as needed.
- Press the SET button a third time and use the ADJ button to change the minutes as needed.

STEP 3: SET THE DATE.

- Press the SET button four times.
- Use the ADJ button to change the months as needed.
- Press the SET button and use the ADJ button to change the date as needed.

STEP 4: SET THE CURRENT TIME.

- Press SET button six times.
- Use the ADJ button to change the hours as needed.
- Press the SET button and use the ADJ button to change the minutes as needed.
- Press the SET button to confirm/set the time and return to the original clock setting.

USING THE PROJECTION FUNCTIONS

- To project the TIME onto the ceiling, press the top of the clock firmly until you feel a "click". You will notice a red light beam projected through the top of the dome's clear panel. The time will now be projected through the clock and on the ceiling.
- To project the MOON AND STARS onto the ceiling, Slide the ON/OFF switch to the ON position. The LEDs will automatically shift through the colors and the stars and moon shapes will be projected onto the ceiling.

TIPS FOR CARE

- To clean, wipe down with a soft dry or damp cloth. Do not use with cleaning agents or other chemical solutions.
- This unit is not waterproof. Do not expose to water, moisture, extreme temperatures, or high levels of humidity.
- Do not attempt to disassemble or modify your clock in any way. Doing so violates any warranty that may have been in place.
- Contact the Customer Support team at tzumi.com/Support for assistance.

PRODUCT SPECIFICATIONS

Batteries Required: 3 x AAA
 Dimensions: 3.5 x 3.5 x 2.5 in.
 Weight: 4.3 oz.